


Product Data

Electrical Data	
Supply voltage	24 V dc, 24 V ac, 115 V ac or 230 V ac
Voltage tolerance	+/- 15%
Power consumption	Max. 6,5 VA
Output: relay	1 open / 1 closed, 250 V ac / 3 A, 120 V ac / 5 A
Output: transistor	40 mA / 30 V dc

Environmental Data	
Temperature, operation	-10 to +50 °C
Sealing class	IP 30
Approvals	

Remote Sensor Series	MPA 41 A/B			MPA 41 C/D		
	100	110	120	100	110	120
	Sensing Range					
Long range	8 m	18 m	35 m	4 m	9 m	18 m
Short range	4 m	9 m	18 m	2 m	5 m	9 m


Illustration



NOTE: Drawing of MPA 41 B


Connection

Wiring Diagram



Wire Code	
R	Red
BI	Black
Y	Yellow
S	Shield

MPA 41 A/C
 4 individual transistor/relay outputs



Wire Code	
R	Red
BI	Black
Y	Yellow
S	Shield

MPA 41 B/D
 1 common transistor/relay output

Connection Steps

- 1 Check the power supply and output of the amplifier type.
- 2 Make sure power is off. Connect all wires according to wiring diagram.
- 3 Turn power on after checking wiring is correct.
- 4 When the amplifier is operating, the green LED (power-on) is on.

Adjustments

Common Output Selection MPA 41 B/D

The common output mode can be selected via dip switch.

Common output standard	Enables the common output to be active (closed) when one or more channels are active. Enables the common output to be inactive (open) only when all channels are inactive.	
Common output inverted	Enables the common output to be active (closed) only if all channels are inactive. Enables the common output to be inactive (open) when one or more channels are active.	

Long/Short Range Selection

Long/short range switch affect to all channels.

Long range	Enables the system to operate at 100% (maximum range).	
Short range	Enables the system to operate at 50% of maximum range, in order to ease sensitivity adjustment at shorter ranges and to reduce the response times.	

Output Mode Selection

The output mode can be individually selected, for each channel, via the dip switches.

Light Operated	Enables the channel output to be inactive (red LED is off) when there is an object present in the detection area. (Thru beam mode)	
Dark Operated	Enables the channel output to be active (red LED is on) when there is an object present in the detection area. (Thru beam mode)	

Sensitivity Adjustment

Maximum sensitivity can be used for most applications and is advised for applications with contaminated environments e.g. dirt, water and dust. Increase the sensitivity to maximum by turning the potentiometer to full clockwise position.

Sensitivity adjustment may be required in applications where objects to be detected are small or translucent. Proceed with the following steps:

- 1 Adjust the sensitivity to maximum by turning the potentiometer to full clockwise position.
 - 2 Check there is no object present interrupting the beam and the sensor pair is correctly aligned and within their specified sensing range.
 - 3 Select target object with smallest dimensions and most translucent surface.
 - 4 Place target object between remote transmitter and receiver sensors. If the output status changes, adjustment is not required. If the output status has not changed proceed to step 5.
 - 5 Decrease the sensitivity by turning the potentiometer counter clockwise until the output changes.
 - 6 Remove target object. Observe the output status has changed.
 - 7 Repeat the procedure for each channel.
- If the signal level is low, the green LED (signal status) will go off. In general, it is recommended to increase the sensitivity till the LED goes on and to check the following:
- Alignment of sensors
 - Transmitter and receiver sensors are within sensing range
 - Sensor heads are not excessively contaminated

Time Delay Adjustment MPA 41 B/D

The on delay enables output signal to only activate if an object in the detection area is present for the adjusted time period. (In Dark operated mode)

The off delay enables output signal to remain activated for the adjusted time period. The time delay is adjustable between 0 - 10 sec.

On delay	Increase or decrease on delay by turning potentiometer clockwise or counter clockwise respectively.
Off delay	Increase or decrease off delay by turning potentiometer clockwise or counter clockwise respectively.



Warning

This product is not a safety system and must not be used as such. It is not designed for personnel safety applications, and must not be used as a stand alone personnel safety system.